




WLN-2000 *Wireless Ethernet* Installation Guide

STATUTORY REQUIREMENTS


Local regulations impose limits on the permitted radiated power from unlicensed equipment. A high gain antenna may be used *only* to compensate for cable losses.

Antenna Installation



NOTES

- All connections must be SELV (Separate Extra Low Voltage <50V AC & < 120V DC)
- Ethernet Port wiring is that of a hub or switch
- Connect "-" terminal to GROUND for surge protection
- Connect M4 screw terminal on rear of module to GROUND for surge protection
- DIO channels can be wired as either inputs or outputs
- Care must be taken with antenna selection and proximity to the radio




Factory Default Switch
RJ-45 Ethernet Connection

Connect M4 screw terminal on rear of module to GROUND for surge protection


RS485 Resistor Termination Switch

RS232 Connections

PCs




PLCs, Dataloggers



9-30V DC Supply

Digital Output Wiring



RS485 Connections

