# **MTL800 SERIES**

**ENCLOSURES** 

# **SPECIFICATIONS**

#### ENC8/ENC8SS:

for 1 MTL831B transmitter. or 1 MTL838B receiver

#### ENC83/ENC83SS: for

1 MTL831B transmitter (for use with 4-wire RTDs)

#### Location

Zone 0, 1 or 2

#### Protection

Dust-tight and waterproof to IEC529:IP67

#### **Construction (ENC8 and ENC83)**

Sheet steel, zinc sprayed and painted RAL7015 grey

#### **Construction (ENC8SS and ENC83SS)** Stainless steel

# Lid

Detachable with lift-off hinges, secured by captive fixing screws with a padlock hasp

#### Earth terminals

Fitted on internal earth rails; accommodate conductors up to 4mm2

#### Number of earth terminals 22

ENC8/ENC8SS: ENC83/ENC83SS:

#### 4-wire RTD terminals (ENC83/ENC83SS only)

32 ready-mounted terminals to accommodate conductors up to 4mm2

## **Gland fixing**

Top and bottom gland plates detachable for drilling by user

18

# Mounting


By fixed mounting lugs

# Weight (excl. transmitters/receivers)

ENC8: 7kg

ENC83: 9.8kg

# **DIMENSIONS (MM)**



	Α	В	С	D
ENC8	331	306	203	306
ENC83	407	380	305	466

The given data is only intended as a product description and should not be regarded as a legal warranty of proper-ties or guarantee. In the interest of further technical developments, we reserve the right to make design changes.

ASIA-PACIFIC: +65 6 487 7887 sales@mtlsing.com.sg

EPS830 RevF 170510

# **ACCESSORIES**

**MTL800 SERIES** 

### **SPECIFICATIONS**

### PCS83 software package (for MTL838B-MBF)

Function: Software configuration of multiplexer system Format: 3.5 inch diskette PC with DOS 2.2, or higher, and a serial (COM) **Requires:** port.

# TO ORDER SPECIEV

TO ORDER, SPI	ECIFY:	
Transmitters MTL831B	Analogue transmitter	
Receivers		
MTL838B-MBF	Analogue receiver, RS485 and/or RS422 outputs for Modbus®	
<b>Analogue receiver</b>	accessories	
PCS83	PC software configuration package	
	<b>interface software</b> details of software for interfacing with ess controllers	
<b>Isolating interface</b>	units and earth leakage detectors	
MTL3052	Digital isolator interface unit	
MTL4220	Earth leakage detector	
Enclosures		
ENC8	General-purpose enclosure	
ENC8SS	General-purpose enclosure (stainless steel)	
ENC83	Enclosure for MTL831B transmitter	
ENC83SS	Enclosure for MTL831B transmitter (stainless steel)	
Literature		
INM838B-MBF	System protocol manual:	
MTI 838B-MBF	Modbus® receivers	

INM838B-MBF	System protocol manual:	
MTL838B-MBF	Modbus® receivers	
INM831B	MTL831B manual	
AN9010	Application Note: A user's guide to intrinsically	
	safe input multiplexer systems	
INS831B	MTL831B mV Multiplexer transmitter	
INS838B	MTL838B-MBF Multiplexer receiver - Modbus®	
	output	

EUROPE (EMEA): +44 (0)1582 723633 enguiry@mtl-inst.com